

## Cut Trim Instructions for the ACS Shafts

### ACS Driver Shafts

**Option 1 - standard**

No tip cut on Driver Shafts

**Option 2 - strong**

1,5" tip cut on the Driver Shafts

### ACS Fairway Shafts

**Option 1 - standard**

From 3-wood to 7-wood: starting with 1,5" tip cut on the 3-wood, continuing with increments of 1" per wood for 5-wood and 7-wood

**Option 2 - strong**

From 3-wood to 7-wood: starting with 2,5" tip cut on the 3-wood, continuing with increments of 1" per wood for 5-wood and 7-wood

### ACS Hybrid Shafts

**Option 1 - standard**

From hybrid-2 to hybrid-5/6: starting with no tip cut on the hybrid-2, continuing with increments of 1" per hybrid

**Option 2 - soft**

From hybrid-2 to hybrid-5/6: starting with no tip cut on the hybrid-3, continuing with increments of 1" per hybrid

### ACS Iron Shafts

**Option 1 - standard**

From iron-3 to PW: starting with no tip cut on the iron-3, continuing with increments of 0,5" per iron

**Option 2 - soft**

From iron-5 to PW: starting with no tip cut on the iron-5, continuing with increments of 0,5" per iron

### ACS Wedge Shafts

**Option 1 - standard**

Tip cut wedge shafts 3,5"

Drivers	1	Fwy. Woods	3	4	5	6	7				
standard	0		1,5 "	2,0 "	2,5 "	3,0 "	3,5 "				
strong	1,5 "		2,5 "	3,0 "	3,5 "	4,0 "	4,5 "				
Hybrids	2	3	4	5	6						
standard	0	1,0 "	2,0 "	3,0 "	4,0 "						
soft	0	0	1,0 "	2,0 "	3,0 "						
Irons	3	4	5	6	7	8	9	PW			
standard	0	0,5 "	1,0 "	1,5 "	2,0 "	2,5 "	3,0 "	3,5 "			
soft	0	0	0	0,5 "	1,0 "	1,5 "	2,0 "	2,5 "			
Wedges											
Wedge	3,5 "										

For any queries please feel free to contact your sales team at:

**Creador® Sport Design**

Industriestrasse 8  
78739 Hardt, Germany

t: +49 7422 / 560 06-0  
m: [info@creador.de](mailto:info@creador.de)

web: [www.acs-schaftmanufaktur.com](http://www.acs-schaftmanufaktur.com)  
[www.acs.creador.de](http://www.acs.creador.de)